

Intergrain UltraDeck Timber Stain on New Weathertex [Exterior]

AU_SW16236

Description
<p>Weathertex is manufactured from 97% Australian Hardwood, and 3% paraffin wax pulped together to form smooth and profiled weatherboards, and exterior wall cladding.</p> <p>Intergrain UltraDeck Timber Stain is a semi-transparent finish, meaning the colour, age and condition of the timber to be stained will impact the final colour and finish. Because of this, any representation of Intergrain UltraDeck Timber Stain colour is to be viewed as a close representation of the colour that can be achieved. Always test on a small area or off-cut for colour suitability before use. The instructions below offer general preparation and application guidelines for exterior timber. For larger projects, cladding, interior, commercial jobs or for more specific information please contact our Help & Advice team.</p>

Summary
<p>In coastal areas or elevations with extreme exposure to UV the optional third coat must be applied.</p>

Substrate And Substrate Preparation	
<p>Substrate Notes:</p>	<p>Weathertex is manufactured from 97% Australian Hardwood, and 3% paraffin wax pulped together to form smooth and profiled weatherboards, and exterior wall cladding.</p>
<p>Substrate Preparation Notes:</p>	<p>Measure the moisture content to ensure it is less than 15% before staining or finishing can commence.</p> <p>Ensure the substrate is thoroughly clean and dry before commencing. Use a scraper to remove dirt, mortar splashes, sap or gum exudation. Examine the surface for the presence of other contaminants.</p> <p>Wash the entire surface with Intergrain Reviva using a stiff bristle brush (being careful not to damage the substrate). Rinse with fresh water and allow to dry.</p> <p>Holes, cracks and other defects should be filled with a water-based wood putty in a shade to suit substrate colour.</p> <p>It is good practice to seal sawn edges and pre-prime the concealed side of any timber mouldings, including corner stops and trims prior to installation.</p>

Coating System Summary	
<p>Prep Coat:</p>	<p>AU_DW02614: Intergrain UltraPrep Timber Cleaner</p>
<p>1st Coat:</p>	<p>AU_DW02613: Intergrain UltraDeck Timber Stain</p>
<p>2nd Coat:</p>	<p>AU_DW02613: Intergrain UltraDeck Timber Stain</p>
<p>Optional:</p>	<p>AU_DW02613: Intergrain UltraDeck Timber Stain</p>
<p>Please refer to the coating system details below</p>	

Coating System			
Coat Type:	Prep Coat	Datasheet:	AU_DW02614 Intergrain UltraPrep Timber Cleaner
Application Methods:	 Other Stiff bristle brush.		
Theoretical Spread Rate *	Min	Max	Recommended
Coating Application Details:	<p>Shake Intergrain UltraPrep Timber Cleaner thoroughly.</p> <p>Mix ONE part Intergrain UltraPrep Timber Cleaner to FOUR parts water in a plastic container. For severely stained surfaces a stronger solution or repeat applications may be necessary. Tannin rich timbers may also require repeat applications; wash until the water used to rinse off is clear.</p> <p>Wet the timber surfaces to be cleaned with water.</p> <p>Apply Intergrain UltraPrep Timber Cleaner mixture generously to the timber with a stiff bristle brush. Scrub the timber vigorously. Spot cleaning should be avoided to prevent patchy results.</p> <p>Leave mixture on the timber for 10-15 minutes. If necessary, apply more mixture to keep timber damp throughout this period, do not allow mixture to dry.</p> <p>Rinse off surface thoroughly using maximum pressure from a garden hose or using a high pressure water cleaner (recommended for large areas or badly discoloured timber). Failure to thoroughly rinse off the mixture may result in timber discolouration under clear finishes.</p> <p>Note: After cleaning, some timber species will appear lighter due to loss of water soluble extractives. Richer colour is generally restored on application of the finish.</p> <p>HELP & ADVICE Australia – 1800 630 285 www.intergrain.com.au</p> <p>NZ – 0800 222 687 www.intergrain.co.nz</p> <p>For detailed project specifications or a Safety Data Sheet, contact Intergrain Help & Advice or visit our website.</p>		

Coat Type:	1st Coat	Datasheet:	AU_DW02613 Intergrain UltraDeck Timber Stain	
Application Methods:	   	Air Spray Airless Spray Brush Pad		
		Min	Max	Recommended
Theoretical Spread Rate *		6	12	
Wet Film Per Coat (microns)		84		
Dry Film Per Coat (microns)		26		
Recoat Time **		See below		
Coating Application Details:	<p>Remove excess water from the surface and allow the timber to dry for at least 1 hour before coating. Stir Intergrain UltraDeck Timber Stain thoroughly before and during use with a flat blade stirrer. It is recommended to test in a small area to ensure satisfaction with the colour and finish prior to staining the whole project, ensure to apply 2-3 coats for the best indication of final colour. Apply Intergrain UltraDeck Timber Stain using the Intergrain DeckBrush (recommended), flat deck applicator, paint brush or spray (air assisted airless or airless). Do not use a roller. Apply at the coverage rate of 6-12m²/L. Do not overspread or apply thinly as insufficient film thickness will result in lap marks and compromise performance and durability. When coating large areas, work in sections, apply long strokes and use natural breaks in the boards as stopping points. If spraying, it is recommended to back brush to even out the finish and avoid spotting. Allow to dry following the recoat time indicated in the section TYPICAL PROPERTIES, then apply a second coat. If necessary, sand lightly between coats to remove any raised grain. A third coat will give extra protection and is required in harsh conditions such as full sun exposure, around pools and in humid areas or if the first coat was applied on damp or porous timber.</p> <p>Important: All timber is required to be free from dust, mould and site contaminants prior to coating. Follow all relevant product label instructions when using Intergrain products. Keep freshly coated contacting surfaces such as doors and windows ajar for several days to prevent sticking.</p> <p>MAINTENANCE Conduct a routine 12 monthly maintenance inspection. Colour fade is the first sign of need to recoat. Best protection of the timber and ease of maintenance is ensured if Intergrain UltraDeck Timber Stain is recoated before deterioration of the coating and timber underneath occurs.</p> <p>HELP & ADVICE Australia – 1800 630 285 www.intergrain.com.au</p> <p>NZ – 0800 222 687 www.intergrain.co.nz</p> <p>For detailed project specifications or a Safety Data Sheet, contact Intergrain Help & Advice or visit our website.</p>			

Coat Type:	2nd Coat	Datasheet:	AU_DW02613 Intergrain UltraDeck Timber Stain	
Application Methods:	   	Air Spray Airless Spray Brush Pad		
		Min	Max	Recommended
Theoretical Spread Rate *		6	12	
Wet Film Per Coat (microns)		84		
Dry Film Per Coat (microns)		26		
Recoat Time **		See below		
Coating Application Details:	<p>Remove excess water from the surface and allow the timber to dry for at least 1 hour before coating. Stir Intergrain UltraDeck Timber Stain thoroughly before and during use with a flat blade stirrer. It is recommended to test in a small area to ensure satisfaction with the colour and finish prior to staining the whole project, ensure to apply 2-3 coats for the best indication of final colour. Apply Intergrain UltraDeck Timber Stain using the Intergrain DeckBrush (recommended), flat deck applicator, paint brush or spray (air assisted airless or airless). Do not use a roller. Apply at the coverage rate of 6-12m²/L. Do not overspread or apply thinly as insufficient film thickness will result in lap marks and compromise performance and durability. When coating large areas, work in sections, apply long strokes and use natural breaks in the boards as stopping points. If spraying, it is recommended to back brush to even out the finish and avoid spotting. Allow to dry following the recoat time indicated in the section TYPICAL PROPERTIES, then apply a second coat. If necessary, sand lightly between coats to remove any raised grain. A third coat will give extra protection and is required in harsh conditions such as full sun exposure, around pools and in humid areas or if the first coat was applied on damp or porous timber.</p> <p>Important: All timber is required to be free from dust, mould and site contaminants prior to coating. Follow all relevant product label instructions when using Intergrain products. Keep freshly coated contacting surfaces such as doors and windows ajar for several days to prevent sticking.</p> <p>MAINTENANCE Conduct a routine 12 monthly maintenance inspection. Colour fade is the first sign of need to recoat. Best protection of the timber and ease of maintenance is ensured if Intergrain UltraDeck Timber Stain is recoated before deterioration of the coating and timber underneath occurs.</p> <p>HELP & ADVICE Australia – 1800 630 285 www.intergrain.com.au</p> <p>NZ – 0800 222 687 www.intergrain.co.nz</p> <p>For detailed project specifications or a Safety Data Sheet, contact Intergrain Help & Advice or visit our website.</p>			

Coat Type:	Optional	Datasheet:	AU_DW02613 Intergrain UltraDeck Timber Stain	
Application Methods:	   	Air Spray Airless Spray Brush Pad		
		Min	Max	Recommended
Theoretical Spread Rate *		6	12	
Wet Film Per Coat (microns)		84		
Dry Film Per Coat (microns)		26		
Recoat Time **		See below		
Coating Application Details:	<p>Remove excess water from the surface and allow the timber to dry for at least 1 hour before coating. Stir Intergrain UltraDeck Timber Stain thoroughly before and during use with a flat blade stirrer. It is recommended to test in a small area to ensure satisfaction with the colour and finish prior to staining the whole project, ensure to apply 2-3 coats for the best indication of final colour.</p> <p>Apply Intergrain UltraDeck Timber Stain using the Intergrain DeckBrush (recommended), flat deck applicator, paint brush or spray (air assisted airless or airless). Do not use a roller.</p> <p>Apply at the coverage rate of 6-12m²/L. Do not overspread or apply thinly as insufficient film thickness will result in lap marks and compromise performance and durability. When coating large areas, work in sections, apply long strokes and use natural breaks in the boards as stopping points. If spraying, it is recommended to back brush to even out the finish and avoid spotting.</p> <p>Allow to dry following the recoat time indicated in the section TYPICAL PROPERTIES, then apply a second coat. If necessary, sand lightly between coats to remove any raised grain.</p> <p>A third coat will give extra protection and is required in harsh conditions such as full sun exposure, around pools and in humid areas or if the first coat was applied on damp or porous timber.</p> <p>Important: All timber is required to be free from dust, mould and site contaminants prior to coating. Follow all relevant product label instructions when using Intergrain products. Keep freshly coated contacting surfaces such as doors and windows ajar for several days to prevent sticking.</p> <p>MAINTENANCE Conduct a routine 12 monthly maintenance inspection. Colour fade is the first sign of need to recoat. Best protection of the timber and ease of maintenance is ensured if Intergrain UltraDeck Timber Stain is recoated before deterioration of the coating and timber underneath occurs.</p> <p>HELP & ADVICE Australia – 1800 630 285 www.intergrain.com.au</p> <p>NZ – 0800 222 687 www.intergrain.co.nz</p> <p>For detailed project specifications or a Safety Data Sheet, contact Intergrain Help & Advice or visit our website.</p>			
Coating System Notes:	<p>* Practical Spreading Rate will vary from the quoted Theoretical Spreading Rate due to factors such as method and condition of application and surface roughness.</p> <p>** Recoat times are quotes for 25°C and 50% relative humidity, these may vary under different conditions.</p>			

Disclaimer

Dulux, Selley's and Other marks followed by ® are registered trademarks. Marks followed by the symbol of ™ are trademarks.

The data provided within the Duspec system is correct at the time of publication, however it is the responsibility of those using this information to check that it is current prior to specifying or using any of these coating/product systems.

DISCLAIMER: Any advice, recommendation, information, assistance or service provided by any of the divisions of DuluxGroup (Australia) Pty Ltd or its related entities (collectively, DuluxGroup) in relation to goods manufactured by it or their use and application is given in good faith and is believed by DuluxGroup to be appropriate and reliable. However, any advice, recommendation, information, assistance or service provided by DuluxGroup is provided without liability or responsibility PROVIDED THAT the foregoing shall not exclude, limit, restrict or modify the right entitlements and remedies conferred upon any person or the liabilities imposed upon DuluxGroup by any condition or warranty implied by Commonwealth, State or Territory Act or ordinance void or prohibiting such exclusion limitation or modification. Coating/product systems can be expected to perform as indicated on the Duspec Spec Sheet so long as applications and application procedures of the individual products are followed as recommended on the appropriate Product data Sheet. "DuluxGroup" "Dulux" "Selley's" "Berger" "Berger Gold Label" "Hadrian" "Walpamur" "Levene" "Acratex" and Other marks followed by ® are registered trademarks of DuluxGroup (Australia) Pty Ltd ABN 67 000 049 427. Marks followed by the symbol ™ are trademarks.

Please note that this document is only valid for 60 days from the date of issue.

DuluxGroup (Australia) Pty Ltd 1956 Dandenong Road, Clayton, Victoria 3168 AU ABN 67 000 049 427